# CC VECTOR

Super USB WiFi Antenna DX

Home Long Range WiFi Receiver System

**Assembly Guide & Mounting Instructions** 

Refer to Quick Start Setup Guide for Further Instructions

CC Vector
WiFi Repeater

USB Connector
into USB Port

Leave Secondary
USB Unplugged


Mount **Vertically** 

Add Silicone Grease to this Connection for Additional Weather Protection. Plug in Tightly and Fully to Insure a Good Connection.

## **Mounting Options**

### Suction Cups for Smooth Surfaces

Slide suction cups onto antenna from top down.



### **Hook and Loop Material**

Remove backing from hook and loop material and press into place on antenna and mounting surface.



#### Cable Tie

Place cable tie around pole or tree limb, and at narrowest part of antenna for best stability.



#### **Detachable Lanyard**









Copyright ©2022 by C. Crane, Fortuna, CA 95540 Phone: 1-800-522-8863 Web: ccrane.com All Rights Reserved. No part of this booklet may be reproduced in any form or means whatsoever without permission in writing from C. Crane.